

Prescriptive Application for HoofGrid Installation

Customer Name: _____
Customer Phone: _____
Email: _____
Physical Address: _____



Type and Location of Specific Installation (stall, run out, paddock ...etc.): _____

A typical, properly installed HoofGrid System:


- (1) remove mud or other debris until a stable, well-draining sub-surface is exposed,
- (2) grade sub-surface evenly (with a slight slope away from the area if possible, although this is not required)
- (3) place a minimum of 2" of 5/8" to 3/4" clean crushed gravel in the area. Spread evenly, then pack using a lightweight vibrating plate compactor.
- (4) Starting at one end or side, place HoofGrid product in place and interlock them by lining them up and gently stepping on them to lock them together
- (5) fill HoofGrid with washed pea gravel and lightly compact using the vibrating plate or landscape drum roller
- (6) add 1" or more of sand for the footing, if desired.

Application recommended for this project:

- Base Preparation:(1) _____

(2) _____
(3) _____
(4) Grid Installation: _____

(5) Grid Fill: _____
(6) Footing / Bedding: _____



Notes or Comments:

Customer Acknowledgment

I understand the proper installation requirements for my specific HoofGrid installation.

Customer Name: _____

Signature: _____

Date: This _____ Day of the month _____, 20__

Eco-Terr Representative

Name: _____

Signature: _____

Phone: _____

email: _____